

Ground Wire Termination

1. Bundle cables together and wrap exposed shield braids with 1-2 layers of 20mm conductive tape. Center tape on shield braids (**Figure A**).



Figure A.

NOTE

If only one cable is terminating to D-Sub, do not wrap with tape.
Secure Micro Band-It Clamp directly on to ground wire and cable shield.

2. Place stripped portion of ground wire over conductive tape (**Figure B**).

Slide Standard Band-It Clamp at the center of ground wire and clamp down (**Figure C**).



Figure B.



Figure C.