

Module Installation & Contact Removal Instructions— Section 1

P/N 910 112 104

PARTS/TOOLS REQUIRED:

Mini Coaxial/Mini Power Receiver/ITA Contact Extraction Tool (VPC P/N 910 112 104)

INSTRUCTIONS:

Receiver/ITA

1. Insert the Mini Coaxial/Mini Power Receiver/ITA Contact Extraction Tool (VPC P/N 910 112 104) firmly over the contact by applying pressure with the shaft. **Do not apply pressure with the handle area.**
2. Apply pressure with the handle area only when the tool has slipped over the retaining ring and has collapsed the tabs (twisting the lower portion of the tool will ensure that the tabs have collapsed). **See Detail A**
3. On the rear side of the module, grasp the contact with your fingers and hold it while removing the tool. This will avoid pulling the contact back into the locked position.

