

4

3

2

1

DO NOT SCALE DRAWING

THE INFORMATION CONTAINED HEREIN IS THE EXCLUSIVE PROPERTY OF VIRGINIA PANEL CORPORATION AND IS SUBMITTED FOR USE BY THE CUSTOMER ONLY. THE DATA SHALL NOT BE DUPLICATED, USED, OR DISCLOSED IN WHOLE OR IN PART FOR ANY PURPOSE OTHER THAN TO MAINTAIN THE EQUIPMENT PROVIDED. CONSULT WITH VIRGINIA PANEL CORPORATION ENGINEERING IF MORE DETAIL IS REQUIRED.

REVISIONS			
REV	DESCRIPTION	DATE	ENGR
F	ECN #15012	5/21/25	R HERRON

CAPTIVE SCREW LOCATION

PIN 1A

PIN 1K

D

D

C


C

B



B

A

A



MATING MODULE VIEW



- NOTES:
1. FOR APPLICATION USE & CARE INFORMATION CONSULT VPC USERS GUIDE @WWW.VPC.COM
 2. FOR MODULE INSTALLATION, INSTALL CAPTIVE SCREW (TOP LEFT) INTO RECEIVER FOLLOWED BY THREE NON-CAPTIVE SCREWS (RIGHT SIDE AND BOTTOM LEFT).
 3. FOR MODULE REMOVAL, REMOVE NON-CAPTIVE SCREWS (RIGHT SIDE AND BOTTOM LEFT) FOLLOWED BY CAPTIVE SCREW (TOP LEFT).

CUSTOMER DRAWING			
VIRGINIA PANEL CORPORATION WWW.VPC.COM			
RECEIVER MODULE 800 POSN CASS			
DIMENSIONS ARE SHOWN AS:	SIZE	CAGE CODE	DWG. NO.
[MILLIMETERS]	C	18117	510113151
INCHES			REV F
SCALE: 1:2		510113151	1/30/2018 SHEET 1 OF 1

4

3

2

1